

eChest Clip



Chest clips are used in child restraints to help position the harness straps correctly in place. But small hands can make big problems. A majority of toddlers can unclip their chest clip on their own. For a little houdini this can lead to a dangerous situation in a moving car.

Our new eChest Clip provides an extra layer of safety by giving off a beeping sound when the child opens the chest clip. So parents can know exactly when it happens.

The eChest Clip has a button cell battery which consumers can easily change by screwing of the lid on the back of the clip.



Technical data

Size: 128 x 47 x 15 mm

Weight: 33 g

Webbing width: up to 40 mm

Push button Ø 25

Button cell battery (CR2032)

Fulfills RoHS, EN62115 and IPC 650

ECE R129

FMVSS
213

CMVSS
213

Safety that never stops